HaWeKo

More than only Consoles! Brunnenstr. 55 70372 Stuttgart

Tel: +49 711 / 794821 03 Fax: +49 711 / 794821 05 Mail: info@HaWeKo24.de Web: www.HaWeKo24.de

Installation Instructions for Navigation Console

VW Touran MY 03-

Item-No.:

VWR075

Perfect Fit

As at: April 07

Page 1 of 2



Caution!

Due to safety reasons pay attention to the course of existing, also non-visible cables, wires and other components which are situated in the installation area!

The console and the components are to be installed in such a way that for the passengers no dangers of injury (i.e. by sharp edges) develop.



Illustration 1:

- Put the rubber mat aside.
- Unscrew the original screw (see arrow) and put aside.



Illustration 2:

Lift the storage box with a flat object (e.g. plastic wedge).



Illustration 3:

Put the storage box aside.

HaWeKo

More than only Consoles! Brunnenstr. 55 70372 Stuttgart

Tel: +49 711 / 794821 03 Fax: +49 711 / 794821 05 Mail: info@HaWeKo24.de Web: www.HaWeKo24.de

Installation Instructions for Navigation Console

VW Touran MY 03-

Item-No.:

VWR075

Perfect Fit

As at: April 07

Page 2 of 2



Illustration 4:

- Attach the console as shown.
- > The two laminate tabs grip into the air outlet nozzle.



Illustration 5:

- ➤ Bend the sheet metals of the console according to the shape of the dashboard.
- ➤ Fasten the two sheet metals of the console (see arrows) with the supplied self-tapping screws.



Illustration 6:

> Replace all removed parts.