

## Installation Manual Double DIN Kit Part-No:. 381323-02

Porsche 911 (type 996) 1997-2006 (with PCM)  models without cupholder
Compatible with double DIN devices
Double DIN Set contents

© 12/2008 ALL RIGHTS RESERVED. Technical changes possible. No liability for misprints.

- (1) Metal Frame
- (2) Installation Kit

• (3) Facia Plate

## **Models with PCM system**



 Insert Porsche radio release keys in the holes of the PCM head unit.

Remove OEM head unit by pulling it towards your direction.



(sample photo)

(sample photo)

Mount the metal brackets to the double DIN head unit.



The position of the copper coloured holder can be adjusted to your needs for perfect fit. (see sample)

Place the facia plate
 on the dashboard.
 Push the metal frame into the
 facia plate.
 Connect all required circuit points
 and push the double DIN head
 unit until it snaps in.
 Place the trim frame.

Reinstall everything in reverse order.

4	 	 	 